



APOLLO

1-566-00

DO NOT REMOVE THIS TAG!

This quality Apollo safety relief valve, along with proper installation, use, and maintenance, will provide many years of reliable service and protection against excessive pressure build-up of air or gas. Use of this valve for any other purpose or media places all responsibility upon the user. Before installing valve, or operating equipment to which it is installed, read all instructions carefully. Always wear proper safety equipment.

INSTALLATION INSTRUCTIONS

MODEL RVA15 (15 SERIES)

- 1) Installation must be performed by qualified service personnel only.
- 2) The SCFM rating of the valve must equal or exceed that of the equipment to which it is installed.
- 3) Insure that all connections, including the valve inlet, are clean and free from any foreign material.
- 4) Use pipe compound sparingly, or tape, on external threads only.
- 5) Use proper type and size wrench on wrench pads only. **DO NOT USE PIPE WRENCH!**
- 6) This valve should be mounted in a vertical, upright position directly to a clean, tapped opening in the pressure vessel. Under no circumstances should there be a flow restriction or valve of any type between the safety relief valve and the pressure vessel.
- 7) **WARNING!** During operation, this valve may discharge large amounts of high pressure air or gas. Therefore, to reduce the potential for bodily injury and property damage, install valve in such a way so as to allow discharge to safely exhaust to atmosphere. **DO NOT CAP, PLUG, OR OTHERWISE OBSTRUCT DISCHARGE OUTLET!**
- 8) See appropriate ASME Boiler and Pressure Vessel Code for additional installation instructions.

WARNING! This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. (California law requires that this warning be given to the consumer in the State of California.)
For more information visit www.apollovalves.com.

DO NOT REMOVE THIS TAG!

maintained.
assume any liability for valves improperly installed or
Neither Conbraco Industries, Inc. nor its agents
personnel.
and contact a licensed contractor or qualified service
of discharge, discontinue use of equipment immediately
If lift lever does not activate, or there is no evidence
lever and permit the valve to snap shut.
to flush the valve seat free of debris. Then release
holding the test lever fully open for at least 5 seconds
Test at or near maximum operating pressure by
protection during valve testing.
Wear ample clothing, gloves, safety glasses, and ear
the discharge ports of the valve during "try lever test".
CAUTION! High pressure air or gas will discharge through
Under normal operating conditions a "try lever test"
must be performed every three years. Under severe
service conditions, or if corrosion and/or deposits are
noticed within the valve body, testing must be
performed more often. A "try lever test" must also be
performed at the end of any non-service period.

MAINTENANCE AND TESTING

Manufactured by Conbraco Industries, Inc.
Made in USA

"Apollo" Valves®

Pageland, SC

APOLLO

